


BUNN® TECHNICAL TRAINING

Ultra



Index

Unit 1: Installation

Site Requirements	4
Location of the Serial Number	4
Prepping Machine for Install	4
Hopper Assembly	5
Electrical Install	5
Powder Autofill (PAF) Installation (Optional)	6
Liquid Autofill (LAF) Installation (Optional)	7

Unit 2: Setup

User Interface.....	13
Switch Operation (Operating Controls)	13
Switch Operation (Programming Controls).....	13
Setup.....	14
Setup Machine.....	14
Product Preparation.....	17
PAF- Powder Mix Set-Up (Brix Ratio).....	17
LAF – Liquid Concentrate Set-Up (Brix Ratio)	18
ULTRA 1 and 2 Start Up with LAF.....	19

Unit 3: Machine Composition

Exterior Overview	21
Removing the Enclosure	21
Machine Function and Operations.....	24
TIC Board (Time In a Can)	24
Main Control Board.....	24
Mechanical System	24
Refrigeration System	24
Temperature Sensing System.....	25
Torque Sensing	25

Unit 4: Preventive Maintenance

Tools Required.....	27
PM Parts	27
Prior to servicing the ULTRA.....	27
Preventive Maintenance Instructions	27

Unit 5: Troubleshooting

Test Menus	30
Test Augers	30
Refill Threshold (Ultra with LAF Kit Installed)	30
Temp and Torque Screen	31
Warning Messages	31
Error Messages.....	33
Product Does Not Freeze or Form Ice Crystals	34
Torque Sensor Board	35
Thermistor	35
Ultra PAF Error Messages	36
Triac Maps	36



Unit Objectives

Given a realistic scenario depicting a new site install, the learner will be able to install and setup the ULTRA for customer turnover without error.

Given a new machine, all the necessary tools and safety equipment, the learner will be able to install the ULTRA without error.

The learner will be able to verify that the site requirements have been met for ULTRA or Optional Accessories.

The learner will be able to locate and document the serial number.

The learner will be able to power up and perform the initial set-up of the ULTRA and Optional Accessory Systems PAF and LAF.

Installation

Site Requirements

Space

- Counter able to support 180 lbs (PAF Accessory Included).
- Minimum clearance of 6" between the machine side and the wall or another appliances
- Counter area able to accommodate machine's footprint with six inches of clearance in the rear for air flow and air filter cleaning.
- Dispenser performs better if not placed near any heating appliance that exhausts heat on and around dispenser.
- Ultra-1 approx. dimensions (H 32 x W 8 x D 24.5)
- Ultra-2 approx. dimensions (H 32 x W 16 x D 24.5)

Plumbing (PAF Only)

- A shut-off valve should be installed in the line before the machine
- Cold water with an operating pressure between 20 and 90 psi (138 and 690kpa) from a ½ inch or larger supply line with a shut off valve.
- A strainer assembly should be installed in line prior to the flexible water line

Plumbing (LAF with Water to Product Ratio Brix Pump with Shut Off)

- Cold water with an operating pressure between 20 and 90 psi (138 and 690kpa) from a ½ inch or larger supply line with a shut off valve.
- Water pressure regulator required and set to 50 psi (345kpa) or SHURflo water pressure reducing valve.
- Double check valve with vent required after pressure regulator.
- 3 - Way Sanitizing Valve required within 6 inches of the brix pump
- Use 3/8 inch I.D. FDA approved flexible beverage tubing and stainless steel fittings with Oetiker clamps.

Water Treatment

- Cold water hook-up only.
- Adequate space for water filter and maintenance.
- Water filter or water cartridge purged before machine installation.
- Installation date recorded on water filter decal.

Electrical


- 120VAC
- Dedicated 15AMP Circuit with proper breaker and receptacle
- Receptacle within 5 feet of machine
- Mating connector must be NEMA 5-15R

Location of the Serial Number

The machine's serial number is located on the data plate, which is located on the right side panel. The serial number half tag can be found on the inside of the machine on the main machine frame.


Prepping Machine for Install

- Step 1:** Verify that all of the site requirements have been met.
- Step 2:** Unbox the machine and all the parts.




- Step 3:** Place the machine in the desired location on the counter. Do **not** lift the Ultra by the drum(s).
- Step 4:** Document the complete serial number of the machine.
- Step 5:** Remove and save the black plastic drum support(s). This will be used as a servicing jig later.
- Step 6:** Adjust the legs on the machine so that it is level or slightly lower in the front.
- Step 7:** Remove the shipping eye bolts, located on the bottom of the machine, from the compressor.


Hopper Assembly




Step 1: Insert the auger nose bushing from inside the hopper.




Step 2: Install the seal(s) over the flange at the rear of the cooling drum(s) and press the seal(s) firmly into place as shown.




Step 3: Align the auger shaft(s) with the auger(s). Push the auger(s) as far as they will go and rotate so the flat face of the auger shaft is aligned with the flat face of the auger nose.




Step 4: Install the hopper over the auger and cooling drum and slide it into place.




Step 5: Push down until the hopper lock plunger snaps into place.




Step 6: Set the hopper lid on the hopper with lamp cord at the back.




Step 7: Plug in the hopper lid lamp cord.




Step 8: Position the faucet seal and the return spring in the faucet valve.



Step 9: Slide the faucet valve assembly into place on the hopper.



Step 10: Press down on the valve to compress the spring. Position the faucet handle over the faucet valve one side at a time and snap into place on the hopper.




Step 11: Install the drip tray and cover.


Electrical Install

- Step 1:** Plug machine into 120VAC outlet.


Powder Autofill (PAF) Installation (Optional)




Step 1: Remove the rear plastic plug from trim strip between the hopper drip trays and loosen the auger motor cover screws.




Step 2: Place PAF platform assembly on top of the motor covers and install support rod into hole in trim strip.




Step 3: Tighten support rod from top of platform. Retighten motor cover screws.




Step 4: Plug RCA cord into Ultra base unit.




Step 5: Install each hopper seal over the flange at the rear of the cooling drums as shown.




Step 6: Press the seals firmly into place.




Step 7: Align the auger shaft with the fin of the auger. Push the augers as far as they will go and rotate them so the flat fin is facing up.




Step 8: Install the auger nose bushing into the front of hopper.




Step 9: Thoroughly rinse the hoppers and install them over the augers and cooling drums.




Step 10: Slide the hopper(s) into place and push down until the hopper lock plunger snaps into place.



Step 11: Install level probes into slots at top rear of PAF hoppers.




Step 12: Install PAF unit onto platform and plug power cord into rear of platform. Plug platform power cord into proper outlet.



Step 13: Assemble the drip tray.

Liquid Autofill (LAF) Installation (Optional)



- The Brix pump should be placed as close to the concentrate supply as possible.
- The Brix pump mounting placement should be the same level or slightly higher than the concentrate BIB.
- Ease of access to the brix pump and sanitize valve for sanitizing procedure.


INTRODUCTION

These instructions are for installing the Liquid Autofill Kits on Autofill ready ULTRA-2 cold drink dispensers. There are three different kits available:


- 37960.0000 ULTRA-2 Liquid Autofill Kit 120V with Separate Water Lines
- 37960.0001 ULTRA-2 Liquid Autofill Kit 120V without Water Lines
- 37960.0002 ULTRA-2 Liquid Autofill Kit 230V with Separate Water Lines

INSTRUCTIONS

1. Unplug machine from power source before removing any panels.
2. Drain both hoppers and clean the machine if needed before proceeding.




3. Remove hoppers, drip tray, both side panels and front panel.



4. Remove both motor covers and locate .50" round knock out in top right area of plastic drum mount.




5. With a standard screwdriver and a hammer, punch out the hole needed for the level probe. Repeat this step for both sides.



6. Install level probe assembly into hole and secure with nut provided.



7. Remove 4 screws holding in the main circuit board.



8. Connect Auto Fill board to main board. Be sure to snap the plastic stand off's completely into the main board.

(Continued)

BUNN-O-MATIC CORPORATION


POST OFFICE BOX 3227
SPRINGFIELD, ILLINOIS 62708-3227
PHONE: (217) 529-6601 FAX: (217) 529-6644



INSTRUCTIONS (Continued)




9. Reinstall the main board into the machine using the original mounting screws.



10. Remove hole covers from the base of the machine as needed to route water and product tubing through base.




11. Install provided bushings into product/water holes to protect the tubing.



12. Plug wire harness (supplied with kit) into AutoFill board connector and route wires back into the machine.



13. Remove top nut off of grounding stud in the base of the machine, add on the green grounding wire from the new harness and reinstall the nut onto the stud. Make sure that all the other grounding wires remain on the ground stud.




14. Install valve and bracket assembly by feeding the attached tubing through the smaller snap bushings in the base of the machine.



15. Connect the wires to the fill valves both water and product as needed according to the wiring schematic provided. Red and White wires to the right valve(s), Blue and white wires to the left valve(s). Please note that Left and Right are from the front of the machine, Users left and right.



16. Route Pink and Tan wires up to level probes and attach using nuts provided. Pink is the right probe and Tan is the left probe.



17. Position the valve and bracket assembly between the right front corner post and the right side fan shroud and secure with screws provided.

INSTRUCTIONS (Continued)



18. Reinstall front panel, left panel and both motor covers.



19. Assemble a .25" quick disconnect fitting, 1.25" neoprene tube and barbed elbow as shown with the .50" barb pointing down.



20. Remove one or both plugs from the hopper depending on whether a separate water line is being installed. Install the quick disconnect fitting into the hole on the hopper and secure with nut provided with fitting.



21. Install hoppers onto machine and slide probes onto hoppers into slots provided.




22. Route the tubes from the solenoids up to the quick disconnect fittings on the hoppers. The tubes are supplied with extra length to allow for trimming if desired. Slip a clamp over the end of the tube and install a .25" male disconnect fitting. Position the clamp over the barb area of the fitting and crimp into place.


NOTE: Make certain the tubes are routed to the correct hoppers to prevent product from being mixed or hoppers overflowing.



23. Connect the tubes to the hoppers.



24. Install customer supplied pump system. Turn on pump system and water supply. Check all tubing connections for leaks.



25. Install snap clamps on to hoses just above the bushings to prevent hoses from being pulled loose from the solenoid valves.

(continued)

INSTRUCTIONS (Continued)

26. Apply power to machine and turn water on for Brix Pump operation. Refer to the Programming section of this manual in the Refill Threshold section to check refill for proper operation.
27. At the threshold screen, with no product in the hopper, confirm the number on the left (top) of the screen is around 250. The number on the right of the screen is factory set to 155. The factory set point should not need any adjustment.
28. After confirming that both hoppers are reading about 250 for the threshold, proceed to the next screen to test the refill circuit.
29. At the test refill screen, select yes.
30. The Activate Valve screen will allow you to test the pumping and refill circuit. Press and hold the ULTRA button to activate the left refill system. Confirm that the left side is filling when the ULTRA button is pressed. Release the ULTRA button to stop the filling process. Repeat this process for the right side by pressing the ICE button to test. Check for leaks at the hoses while pumping system is running.
31. Once the testing is complete, exit the programming menu and reinstall the right side panel.
32. The auto fill feature can be turned on by pressing the auger button for each side until the display reads "AUGER REFILL ON".

NOTE: Some models also include a "Delay Refill" option. This feature is used to dose in small amounts of new product while delaying between doses. This can help the already frozen product from becoming deluted and not ready to serve. These delay and fill times are to be determined and set based on each application as desired by the end user.



UNIT 2 SETUP

Unit Objectives

Given a realistic scenario depicting a new site install, the learner will be able to install and setup the ULTRA for customer turnover without error.

Given an installed machine, all the necessary tools and safety equipment, the learner will be able to set the machine up for initial operation.

The learner will be able to operate the switch controls.

The learner will be able to enter and navigate programming.

The learner will be able to understand and perform the task of setting priority menus.

The learner will be able to perform product preparation and adjustments of the optional accessories (PAF & LAF).


User Interface

Using the menu-driven display on the front of the dispenser, the operator has the ability to operate, alter or modify various parameters such as beverage consistency and set day/night “ON/OFF” times. The operator is also prompted to check a variety of periodic service functions or even a step-by-step cleaning routine.

Ultra 1



Ultra 2



Switch Operation (Operating Controls)



This switch is the ON/OFF toggle switch which powers up the dispenser and the LCD display. This switch is also used as back up switch in menu mode.



Press and release the appropriate (ON/OFF) switch to start the Auger Motor and to turn on AutoFill when applicable.



Press and release the (OFF/ICE/CHILL) switch and select CHILL to begin the cooling process for the selected hopper.

Switch Operation (Programming Controls)

To access the programming mode, and to scroll through the different function screens, hidden programming switches are used. Press and hold for five seconds the “Gourmet” button to enter into the programming menus.

“ULTRA” (left under display)

When prompted by a selection from the menu to answer yes or no, the “ULTRA” switch is used to answer “NO” or (-) minus.

“GOURMET” (center under display)

Press and hold this switch 5 seconds to access the Menu Function Index. This switch is also used as “NEXT” to scroll through the functions.

“ICE” (right under display)

When prompted by a selection from the menu to answer yes or no, the “ICE” switch is used to answer “YES” or (+) plus.

Setup

Setup Machine

The following machine parameters should be set upon placement of machine for product turn over.

- Set Thickness (Product consistency)
- Set Date Time
- Set Language
- Set Night Time
- 6 Month PM (Recommended)
- Day To Clean (Recommended)

LAF Set Up Menus

- Delayed Refill
- Enable Refill ? (Ultra-1 Only)

Set Thickness

Setting the thickness changes the ice consistency, or torque of each auger. The factory default is 8 with a range of 1 to 16.

Step 1: Press and hold the Gourmet switch until the display screen reads “Cleaning Guide?”.

Step 2: press and release the Gourmet switch until the “Set Thickness?” option is shown in the display screen.



Step 3: Select Yes (Ice) to access the Set Thickness option.

Step 4: Use Min (-) and Max (+) to adjust the thickness levels. Press the Gourmet switch to accept the desired setting for the left side.



Step 5: Use the same controls to adjust the thickness level for the right side. Press the Gourmet switch to accept the desired setting.



Step 6: Press Next (Gourmet) until you exit programming and return to the Home Screen.

Set Date Time

Allows the operator to set the DATE (YY MM DD) and TIME (HR MIN SEC) for display on the Home Screen.

Step 1: Press and hold the Gourmet switch until the display screen reads “Cleaning Guide?”.

Step 2: Press and release the Gourmet switch until the “Date/Time” setting option appears in the display screen.




Step 3: Select Yes (Ice) to access the set Date/Time option.

Step 4: Use Min (-) and Max (+) to adjust the setting to the appropriate year. Select Next (Gourmet) to continue.



Step 5: Use Min (-) and Max (+) to adjust the setting to the appropriate month. Select Next to continue.



Step 6: Use Min (-) and Max (+) to adjust the setting to the appropriate day. Select Next to continue.



Step 7: Use Min (-) and Max (+) to adjust the setting to the appropriate hour. Select Next to continue.



Step 8: Use Min (-) and Max (+) to adjust the setting to the appropriate minute. Select Next to continue.



Step 9: Use Min (-) and Max (+) to adjust the setting to the appropriate second. Select Next to continue.



Step 10: If you are satisfied with the changes, keep pressing Next (Gourmet) until you exit programming and return to the Home Screen.

Set Language


The setting of the Set Language mode allows the operator to scroll thru a list of languages stored in the software and select one for the display messages.

Set Night Time


The setting of the Day/Night mode allows the dispenser to “power down” during off hours. The bottom corners displaying “ICE” will change to “CHILL” during the night mode. During the night mode, the product will be kept chilled to below 35°F. “ICE” reading will return after night mode elapses. With “OFF” representing 12:00 AM, the operator can scroll to the times desired for the night time mode to begin and end.

Step 1: Press and hold the Gourmet switch until the display screen reads “Cleaning Guide?”.

Step 2: Press and release the Gourmet switch until the “Set Night Time” setting option appears in the display screen.



Step 3: Use Min (-) and Max (+) to adjust the setting to the desired time. When finished, Press and release the Gourmet switch and proceed to Day Time setting.




Step 4: Use Min (-) and Max (+) to adjust the setting to the desired time. When finished, keep pressing Next (Gourmet) until you exit programming and return to the Home Screen.

6 Month PM

This function is used to set a reminder message Preventive Maintenance Due every six months. The machine will not shut down if service is not performed. When the service is performed and the message, “PM COMPLETE?”, is answered “YES” (ICE), the time and date is recorded for another six months to elapse.

Step 1: Press and hold the Gourmet switch until the display screen reads “Cleaning Guide?”.

Step 2: Press and release the Gourmet switch until the “6 Month PM” setting option appears in the display screen.



Step 3: Use Min (-) or Max (+) to turn this function on/off. If you are satisfied with the changes, keep pressing Next (Gourmet) until you exit programming and return to the Home Screen.



Day To Clean

This function allows the operator to program a cleaning schedule from 1 to 14 days.

Delayed Refill


This function allows the operator to dose in small amounts of new product while delaying between doses. This can help the already frozen product from becoming diluted and not ready to serve. These delay and fill times are to be determined and set based on each application as desired by the end user.

Enable Refill (Ultra-1 Only)

This function will activate the Liquid Autofill function only in machines equipped with the LAF option.

Product Preparation

Whether liquid concentrate or granulated powder, all product must be thoroughly mixed BEFORE adding it to the hoppers.



For best results with granita-type products, use only products with an apparent brix of 12 or higher. Some products may work with an apparent brix as low as 9. Your experimentation with other products will be the best guide in this area.

Keep the pre-mixed liquid product refrigerated. This reduces cooling/freezing time in the dispenser.

Keep the hoppers topped-off during peak serving periods. Add pre-mixed liquid product as it is dispensed. This reduces the cooling/freezing time and assures you of always having product ready to dispense.

Keep the product level in the hoppers higher than the auger. If the auger is exposed, air will become entrapped in the mixture resulting in a clouded foamy consistency.

You may find it beneficial to turn down the ice controls to keep the ice granules from growing too large.

Some products freeze at a lower temperature than others. You may notice frost or ice on the hoppers. This is normal and should not be a concern.

Humidity in the air may cause sweating on the outside surfaces of the hoppers. This is to be expected and should not be a concern. The drip trays beneath the hoppers will capture this and cause it to flow to the lower drip tray for disposal.

Some noises are to be expected during normal operation of the dispenser. By becoming familiar with the noises made during normal operation, you will be better able to listen for problems.

PAF- Powder Mix Set-Up (Brix Ratio)

When using the PAF with a new powdered granita mix, follow the procedure outlined below to adjust the PAF to produce the correct brix ratio according to the product manufacture.

Step 1: Determine the mix ratio of powdered granita mix. Convert the recipe so that it is expressed in terms of weight units [grams (g), dry ounces (oz), or pounds (lbs)] of powdered granita mix to fluid ounces (fl.oz.) of water [1 gallon (gal) = 128 fl.oz.; 1 liter (l) = 33.8 fl.oz.].

Step 2: The delivery rate of the water ingredient is factory preset to 1 fl.oz. per second. Therefore, it is only necessary to adjust the delivery rate of the powdered granita mix.

Step 3: Place the PAF on top of a fully assembled ULTRA taking care to align the PAF guide rails over the rollers on the platform guide rails.

Step 4: Connect the PAF power cord to the outlet located on the ULTRA auger motor cover.


Step 5: Attach a flexible water line to the .25" flare fitting on the back panel of the PAF.

Step 6: Ensure the ULTRA is powered ON and the Day/Night setting is set to Day.

Step 7: Pull the PAF fully forward on its support rails.

Step 8: Pull the slide gate closed on the PAF product hopper elbow and remove the product hopper from the PAF.

- Step 9:** Remove the lid from the product hopper and fill the hopper with a powdered granita mix.
- Step 10:** Install the product hopper into the PAF.
- Step 11:** Place the ON/OFF switch at the PAF whipper panel to ON.
- Step 12:** After allowing 5 seconds for the PAF to initialize, observe the door lamp on the whipper panel. The door lamp should not be lit. If the door lamp is lit, consult the fault list and clear the fault before proceeding.
- Step 13:** Remove the hole plug on the whipper panel. Using a slotted screwdriver, set potentiometer to approximately mid range.
- Step 14:** Remove the mixing chamber from the PAF and place a small container, such as a cup, under the product hopper ejector elbow.
- Step 15:** Push the slide gate on the product hopper ejector elbow to the OPEN position.
- Step 16:** Momentarily set the TEST/SERVICE switch on the whipper panel to the TEST position. The hopper motor will run and dispense powdered granita mix for 10 seconds.
- Step 17:** After the PAF has finished the 10 second throw test, weigh the dispensed product.
- Step 18:** Determine the dispense rate of the powdered product (weight units per second) by dividing the measured weight by 10.
- Step 19:** Compare the measured dispense rate with the mix ratio in Step 1. Adjust the MIN/MAX control clockwise to increase the dispense rate or counterclockwise to decrease the dispense rate of the powdered granita mix. Repeat Steps 16 through 19 as necessary until proper mix ratio is achieved.
- Step 20:** Once the mix ratio has been adjusted, the PAF can be run with the door open. This will allow you to catch dispensed product for brix testing.
- Step 21:** Hold a container under the dispense tip of the PAF.
- Step 22:** Hold the TEST/SERVICE switch on the whipper panel to the SERVICE position.
- Step 23:** When the container is filled to the desired level, release the TEST/SERVICE switch.
- Step 24:** Measure the brix using the appropriate measuring device.
- Step 25:** Remove the hole plug. Using a slotted screwdriver, adjust the potentiometer clockwise to increase the brix or counterclockwise to decrease the brix of the product. Replace the hole plug.




Adjustment for Powder Throw Weight

LAF – Liquid Concentrate Set-Up (Brix Ratio)

The SHURflo BRIX proportioning pump is driven by pressurized water, allowing the water and product to be delivered at an exact ratio. The pump operates whenever there is a differential in pressure between the inlet and outlet water sides of the pump.

- Step 1:** Purge water filter if applicable and confirm all water devices are properly placed, tubing connections are properly clamped and lines are not kinked.
- Step 2:** Install the BIB connector onto the receiving product container.
- Step 3:** Locate concentrate and water tube that will connect to the quick disconnect fittings on the hopper, place water and concentrate tube inside of an empty container to prime the concentrate and the purging of air out of the lines.
- Step 4:** Check 3 –way sanitize valve for dispense position and slowly turn on the main water supply.
- Step 5:** Allow the pump enough time to purge all the air out of the lines and check for desired flow rate of product and water. Adjust pressure regulator if applicable or adjust water shut off valve if using a fixed water flow regulator. When the desired flow rate is achieved, turn off the water supply.
- Step 6:** See hopper assembly instruction sheet. Install level probe onto the hopper.
- Step 7:** Connect the tubes to the hopper quick connect connectors. Keeping the water and concentrate line accordingly to the correct hopper on a two hopper machine.
- Step 8:** Turn on the water supply and the machine is now ready for start up and initial fill of the hopper.



ULTRA 1 and 2 Start Up with LAF

Step 1: Review the switch operation of the user panel.

Step 2: Apply power to the machine.


Step 3: Press and release the (ON/OFF) switch to power on the machine.

Step 4: ULTRA with LAF option: Press and release the appropriate (ON/OFF) auger switch until the appropriate "Auger Refill On" mode is selected. This mode activates the motor and refill circuit in unison and will automatically maintain the level of product in the hopper to the probe level.

Note: ULTRA-1 only – Enable the refill menu in the programming to activate the liquid autofill function.

Step 5: Press and release the (OFF/ICE/CHILL) switch until the appropriate mode is selected (ICE).

Step 6: The cooling process is now activated and cooling will begin after a sequence delay within the start up or activation of the cooling system.



Ultra 1 Only (Step 4)



UNIT 3 MACHINE COMPOSITION

Unit Objectives

Given a realistic scenario in which the learner has access to the machine's internal components the learner will understand the composition and functions of the machine.

Given a realistic scenario requiring the learner to access the internal components of the machine the learner will be able to remove the top motor covers, side panels and front control panel.

Given an operating machine the learner will be able to give a general explanation of how the machine operates.

The learner will be able to identify the components and functions of the mechanical system.

The learner will be able to identify the components and functions of the refrigeration system.

The learner will be able to identify the component and function of the temperature sensing systems.

The learner will be able to identify the components and functions of the remaining components not comprised in the identified systems.

Machine Composition

Exterior Overview

Product outlets and removable parts


- Hopper outlet(s)
- Drip tray
- Hopper(s)
- Auger(s)
- Faucet(s)
- Hopper lid(s)
- Air filter



Removing the Enclosure

The majority of the service work done to the ULTRA will require the service technician to access the inside of the machine. The ULTRA enclosure is comprised of two side panels, front control panel and two top motor covers to facilitate access to the refrigeration and electrical components.

Depending on the repair the technician may have to remove one or all of these panels. In order to work safely the power should be disconnected prior to removal of any body panel. Once the panels and drip tray are removed, the power can be reconnected in order to troubleshoot the machine.




Front Control Panel

Removing the front control panel will give you access to the main control board, Tic board, switch membrane ribbon connection and hopper drip tray drain tubes.


How to Remove

The control panel is attached to the main housing by 1 hex slotted and 2 standard slotted screws.

The left and right side panel will need to be removed first to give access to the single standard slotted screw on each side. One ¼ inch hex slotted screw is located in the front support bracket located in front center behind the drip tray.



The front control panel is now ready for final removal by pulling downward and away from the machine. Be cautious upon removing the panel because of the switch membrane connection.




Left Side Panel


Removing the left side panel will give you access to the refrigerant solenoids, hot gas sensor/thermistor and optional LAF water valve/ULTRA-1 only.

How to Remove

The left side panel is attached by 2, 1/4 inch hex slotted screws on the underside. Remove or loosen the screws and the panel is now ready for removal by pulling downward and out.



Hot Gas Sensor




Solenoids

Right Side Panel

Removing the right side panel will give you access to the hood light relay, lamp circuit breaker, compressor relay, stepdown transformer, condenser fan/ULTRA-2, compressor starting components and optional LAF water valve/ULTRA-2 only.

How to Remove

The right side panel is attached by 2, ¼ inch hex slotted screws on the underside. Remove or loosen the screws and the panel is now ready for removal by pulling downward and out.




Top Motor Covers

Removing the top motor cover per side will give you access to the auger motor, start/run capacitor, torque sensor board, evaporator thermistor and auger shaft assembly plus bushing and seal.

How to Remove

The motor cover is attached by 2 slotted standard screws in the rear per side. Remove the screws and the motor cover is now ready for removal by pulling backwards.



Machine Function and Operations

TIC Board (Time In a Can)

A Tic/Memory Clock is connected and located behind the main control board. The time and date is recorded after 100 hours of continuous power. The control board is checking the tic for clock information on a regular basis. If the communication is lost with the tic board, the CBA will keep trying to establish communication several times before it determines that the tic is no longer communicating or it is disconnected.

The result will be:

- Machine will display a message “Bad Tic Clock”
- Machine will operate in default mode by turning the Augers On and Chill mode. This is done to keep product chilled.
- Denied access to programming by display message “Operating in Default Mode”
- Turn the power switch on, machine will restore defaults automatically. You will see a countdown number along with restoring default message.

Main Control Board

The main control is the brain of the machine. The control board is the single component that contains all of the programming software, it interprets all the data it receives from the level probe (LAF & PAF), temperature sensors, switch inputs and torque monitor/sensor board. The input data received will command accordingly to turn on the outputs to maintain a cold or ice product in the hopper.


Mechanical System

The mechanical system mixes the product, shaves the product from the cooling drum and pushes the product forward during dispensing mode. The product mixing and dispensing occurs as the auger motor rotates the auger. The auger will stop and run counterclockwise for 2 minutes on the hour or during a certain sequence that takes place with time and temperature of the product.

The thickness of the product is measured with a torque sensing system. This system utilizes two pins, one located on the auger shaft and one located on the auger motor shaft. The auger shaft is connected to the auger motor shaft via torsion springs, which allow the two pins to separate under torque. The distance between the pins is measured with a torque sensing board that emits a light beam every time the beam is broken by the pin on the auger motor. A signal is sent (voltage) to the main control board. The main control board processes this information and energizes/de-energizes the refrigeration system as needed to keep the product thickness consistent. The dispense system or faucets are manually operated by pulling down on the faucet handle until cup is full then release handle.

Refrigeration System


The cooling system for the Ultra is designed to make a frozen slush. This is accomplished through the use of a torque monitored refrigeration system. Upon initial startup of the machine, the compressor and fan will turn on after a delay. The amount of time for the delay is based on the cooling drum temperature. For instance, if the thermistors sense that both barrels, (one for Ultra-1), are above 50° F when the machine is powered up, the delay time is 1 minute. If any of the barrels are below 50° F, then the delay time is 6 minutes. Once the compressor and fan are operational the removal of heat from the product begins, cooling the product to programmed consistency. The thickness, (consistency), is set within the program menu and can range from 1 to 16. The thickness setting is 3 times the number, which is related to torque. The programmed setting is the operating parameter for the torque circuit, which monitors the product thickness. When the torque circuit determines the desired thickness is achieved the corresponding refrigerant valve is turned off and the compressor remains on for 30 seconds. If during this time the processor determines that cooling is still needed in the barrel(s), then the valve will open and the compressor continues to run. When the torque reading stays above the desired set point for over 30 seconds, then the microprocessor will shut off the output to the compressor relay coil, which turns off the compressor. The condenser fan runs for an additional minute after the compressor has shut down. Once the compressor has shut down it requires a 6 minute delay before it can restart.



The system will determine if cooling is needed based on the torque reading. The actual setting that the processor uses is 3 times what the user has set in the menu. For instance: if the setting is at 10, then the system will turn the refrigerant valve off at 30. But also keep in mind that we have some hysteresis programmed into this setting, which is plus 1 and minus 2. This means that the valve will turn off above 31 and will not come back on until it drops below 28.

Temperature Sensing System

The Ultra uses a thermistor to monitor the actual temperature of each cooling drum. Night and Chill modes maintain 35° F, instead of the torque sensing board (product thickness).




Torque Sensing



The torque springs within the auger shaft assembly will flex depending upon the amount of torque applied to the torsion springs by the cooling of the product which creates ice crystals. The ice crystals size relates to the size of the gap created between the two pins (auger motor pin & auger shaft pin). The "thickness" adjustment menu ranges from 1- 16 which sets the target gap between the pins.

Note: Product with high sugar content above 12 brix or alcohol will be a factor in longer freeze times. The product will need to go much lower than 32° F. before it may or may not form ice crystals.

*Starts Freezing
1/4" Gap Minimum*



*Stops Freezing
1/2" Gap Maximum*





UNIT 4 PREVENTIVE MAINTENANCE

Unit Objectives

Given a realistic scenario depicting a machine requiring a preventive maintenance, the learner will be able to identify which elements of a component need to be serviced without error.

Given a machine, all the necessary tools and safety equipment, the learner will be able to identify the components that need to be serviced for the PM.

Preventive Maintenance

In order to maintain proper operation and long service life BUNN recommends performing the preventive maintenance every 6 months. Some of the PM items may require more frequent maintenance depending on the site conditions and usage. Failure to perform these procedures may result in damaged equipment and may not be covered by warranty.

Tools Required:

- Small & Medium standard blade screwdriver
- Medium philip screwdriver
- ¼ inch ratchet set
- Basic misc. size wrenches
- 2 Clean 5 gallon buckets
- Sponge
- Cloth or towel
- Extended bristle brush (PN: 40500.1068)
- Food grade lubricant (PN: M2550.0001 – 1 ounce Lubrifilm)
- Krytox Grease (PN: 29563.0000 - .08818 oz. or M2548.1000 – Bulk oz.)
- Condenser Cleaner
- Rubber gloves
- Safety goggles or face shield
- Fin Comb
- Vacuum with brush attachment
- Mild non abrasive detergent

PM Parts

- ULTRA 1 PM Kit – PN: 34245.0002
- ULTRA 2 PM Kit – PN: 34245.0000

Prior to servicing the ULTRA:

- The ULTRA has an optional menu setting that may alert the operator when Preventive Maintenance is due by displaying a message on the display, the message will read “Shaft Seal Maintenance Due”. The message will not shut down the machine if the service is not performed. The technician will need to be aware to reset the menu by answering “yes” in the “PM Complete ?” menu located in the programming section. Be aware that the menu might be password protected. Once you answered the menu with “yes”, the time and date is recorded for another six months to elapse.
- The ULTRA may have the optional LAF and PAF accessories installed and will require turning off the main water supply.
- Unplug or disconnect ULTRA and/or PAF Platform from power.
- Drain hoppers of product into clean holding containers and ask store manager to store product in a cooler or refrigerator.
- Remove hopper assemblies and ask store manager to perform the necessary cleaning procedure of the hoppers while you perform the preventive maintenance.

Preventive Maintenance Instructions

Step 1: Shaft Seal Maintenance (PM Kit Required)

- Drain, remove and clean hopper; refer to the Operating and Service Manual for proper cleaning procedures. Discard the hopper/drum seal and faucet seal.
- Remove the #8 locking screws securing auger motor cover to the cooling drum mount assembly; remove cover and set aside for reassembly.




Figure 1

- Remove the #8 locking screw on the lower right side (viewed from front) of the auger motor mounting bracket securing the auger motor run capacitor. Set capacitor aside with wires attached.
- Disconnect the auger motor terminal from the terminal on the main wiring harness.
- Remove the remaining #8 locking screws securing the cooling drum mounting bracket. Remove motor with mounting bracket.

Note: When removing or installing motor and shaft assemblies, be sure the split pins are turned to a position that will clear the torque sensor circuit board.

- Pull the auger shaft assembly straight out of cooling drum. Inspect the shaft for abnormal wear.
- From the front of dispenser, remove the seal and blue bushing from cooling drum and discard them.
- Clean seal and bushing surfaces of the cooling drum very thoroughly. Lubricant is not required on any of the seals or bushings.
- Refer to Figure 1, and slip new blue bushing into cooling drum.
- Place seal on insertion tool as shown in Figure 2. Make sure open face of seal is toward cooling drum.
- Push seal into bore until it is firmly seated; remove tool.
- Place a small amount of “Krytox” lubricant (provided in kit in a plastic cap) on the end of the motor shaft (about 1 1/2”) and a thin film in the groove. Install auger shaft assembly onto the motor shaft. See Figure 3. Do not use too much “Krytox” lubricant. This is the only place “Krytox” lubricant is used.
- Assemble motor/shaft assembly as shown in Figure 3, then install assembly into cooling drum. Make sure the pins do not hit the sensor board and cooling drum seal is not dislodged as the shaft passes through.
- Secure motor and capacitor to the cooling drum mounting bracket. Install rear motor cover.
- Refer to the Installation and Operating Manual for hopper assembly and installation procedures. Install new hopper/drum seals and faucet seals included in the kit. See Figure 1 and 4.
- Remove and clean condenser air filter. See Figure 5.
- Refer to the Installation and Operating Manual, “Menu Function Index”. Scroll to menu “PM Complete?” and answer “YES” to reset the reminder message “PM Due”.





Figure 2



Lube about 1 1/2” of shaft and in the groove with BUNN P/N: 29563.0000 “Krytox” Lubricant

Figure 3




Figure 4




Figure 5

Step 2: Air Filter

- The air filter will need to be cleaned on a monthly basis or sooner dependent upon environment conditions and usage. Wash stainless filter in a sink with warm soapy water and dry.

Step 3: Cleaning the Condenser/Fins

- Use a soft cleaning brush attachment, gently vacuum the condenser coil fins.
- Using a flashlight, shine the light through the condenser fins to re-check for cleanliness or dirt between the fins.
- Heavy build-up of grease in the condenser may require the use of a commercial condenser cleaner.
- Follow the warning and safety instructions along with the how to instructions supplied with the cleaner.

UNIT 5 TROUBLESHOOTING



Unit Objectives

Given a realistic scenario depicting one of several possible machine malfunctions, the learner will be able to effectively troubleshoot, diagnose and repair the malfunction before returning the machine to normal operation.

Given a machine displaying an error or warning message, all the necessary tools and safety equipment, the learner will be able to access the programming and use component test menus as a tool to assist in the diagnosing process.

The learner will be able to navigate to the component testing menus. (Test Augers & LAF Menus L & R Refill Threshold and Test Refill)

The learner will be able to access the “Temp and Torque” screen.

Given a list of error and warning messages, the learner will be able to give an explanation of the error and warning messages.

Given a realistic scenario when product does not freeze or chill, the learner will be able to diagnose other possibilities other than a failure in the refrigeration system.

The learner will be able to troubleshoot the torque (ice) system.

The learner will be able to use the “Temp and Torque” screen as a troubleshooting tool.

The learner will be able to troubleshoot the chill mode.


Troubleshooting

Test Menus

The ULTRA machine features a few testing menus. Enter programming and navigate to the menus to test the auger motor in forward and reverse rotation and check the operation of the LAF product level circuit and water valve for electrical activation.

Test Augers

This function tests the operation of forward and reverse of each auger motor. Left auger appears first. Press the ICE hidden switch to toggle between OFF, FORWARD and REVERSE. Press GOURMET hidden switch to repeat the operation for the right auger motor. A one minute time out will return to the Home Screen.




Select NEXT to repeat process for Right Auger Test.
Note: ULTRA-1 models will only have one test screen.

Refill Threshold (Ultra with LAF Kit Installed)

This function allows the operator to adjust the Refill Threshold depending on the type of product being dispensed.

Test Refill: Test menu by turning on the output to the corresponding water valve.



The water threshold is factory set at 155, a common threshold used throughout the Bunn beverage equipment. The number on the left can be used as a tool to see the operation of the refill circuit and can be adjusted accordingly to the conductivity (TDS) of the product or water. The threshold 155 normally will not need to be adjusted on the Ultra machine but is mainly for geographical areas where naturally soft water is present or customers using water purification systems (reverse osmosis) on coffee equipment.

Example: Product reads “8 on L REFILL 155” menu when product is touching level probe. Product leaves level probe and the 8 starts increasing in value, the number will go higher than the threshold of 155, the CBA will activate the refill circuit to turn on and fill the hopper. Once product touches the level probe, the product number reading on the left will come down below the threshold setting number 155 and indicate to the CBA that the level probe is satisfied (number < 155) with product. The refill circuit is satisfied and will turn off.

Number range 0 – 255


Threshold 155 – adjustable for natural soft water condition or use of water filter purification.

Reading < than 155 means satisfied or shorted circuit

Reading > than 155 means call for refill or open circuit

Temp and Torque Screen

Press and hold for five seconds the ULTRA and ICE hidden switches to display the TEMP & TORQUE. The temperature of each cooling drum and the hot gas temperature will toggle back and forth. The auger torque is displayed continuously during machine operation. Press and release the ULTRA and ICE hidden switches to return to HOME SCREEN. The TEMP & TORQUE mode is typically used for service.




Notice: While in the TEMP & TORQUE screen, the UPPER/lower case will be replaced by symbols. The symbol is used for reference, illustrating when the solenoid is on or off. The screen can be used to see the possibility of a dirty filter or the condition of the auger shaft torsion springs by the thickness setting multiplied by three during machine operation. No load on the auger shaft torsion spring during rotation will start from thickness setting multiplied by three and countdown to zero. If zero is not achieved and a number is represented, this is an indication of a worn torsion spring in the auger shaft.


Warning Messages

Clean Filter Message

A monthly counter will automatically show the warning message to clean the condenser filter. If the filter is not cleaned and the machine detects a rise in temperature, the message will escalate to the next level of cleaning the filter and eventually will disable the machine from freezing (ice).




The machine will also display the number of day's pass due on the display.





Clean Due Today Message

The messages come from the activation of the "Days To Clean" menu. It can be set up as a clean message only or set as a clean lockout. To reset the Clean Due Today message or lockout, two functions must be performed. Either power off the dispenser using the I/O (ON/OFF) switch and allow the barrels or cooling drums to warm over 50°F. Scroll to the Cleaning Guide and perform the cleaning service. The barrels will warm to over 50°F when cleaned with warm water and the message will disappear.



Error Messages




Product Does Not Freeze or Form Ice Crystals

When the product does not freeze, there are several possibilities other than a failure in the refrigeration system.




1. Product is very high in brix (sugar) or alcohol.

2. The torque between the auger motor and the frozen product is controlled by the torque sensor board measuring the distance between the pins on the coupler and shaft. When the distance between the pins reaches the maximum allowable distance, the compressor shuts off. The machine thinks the product thickness has reached the maximum and shuts off the compressor. The illustration below shows some of the other possible causes for a false reading from the torque sensor board.

Normal Operation



Possible Causes for False Readings




Torque Sensor Board

The motor pin and auger shaft pin rotate between the LED (red) and photo transistor on the board, interrupting the infra red beam. The microprocessor calculates the distance between the pins and determines the refrigerant solenoid shut off point based on the programmable “thickness” setting per side.

Troubleshoot the torque board by blocking and unblocking the infra red with an object while monitoring with a voltmeter. If the meter displays 5vdc when blocked and 0vdc when unblocked, then the Torque Sensor is good. If there is no 5vdc reading, verify that both red and white sensors are clean.

Blocked – 5 vdc
Unblocked – 0 vdc



Thermistor

The thermistor or temperature sensors are located inside the top rear of the cooling drum. The resistance value changes according to barrel temperature which correlates a change in voltage. The “Temp and Torque” screen can be used to see barrel temperature. The thermistor can be checked by resistance or voltage. Connect a voltmeter, across the two leads of the temperature sensor (leave plug connected);

The indication must be:

- a) Approx. 1.4 vdc @ 71° F
- b) Approx. 2.6 vdc @ 32° F


If voltage reading is 0v, the Control Board is not supplying the necessary 5v and should be replaced. If the reading stays at 5vdc, replace thermistor.

Resistance Check

Disconnect the plug on thermistor leads and check resistance as indicated below.

The indication must be:


- a) 5650 ohms @ 32° F ± 10%
- b) 2000 ohms @ 77° F ± 10%



Ultra PAF Error Messages


Door Lamp	Fault
On	Normal operation the Powder Autofill is ready to dispense.
Flashes On/Off at 50% duty cycle	Low product level in Powder Autofill hopper.
Two flashes about every 2 seconds	Ultra/Powder Autofill probe circuit open.
Three flashes about every 2 seconds	Powder Autofill hopper not in place.
Four flashes about every 2 seconds	Ultra refill exceeded 5 minutes.
Off	Door not closed.

Ultra 1 Triac Map




1. TH1 = Auger
2. TH2 = Compressor Relay
3. TH3 = Refrigeration
4. TH4 = Refill Valve (not currently offered)
5. Q4 = Fan

Ultra 2 Triac Map (Bunn P/N 38710.xxxx)



1. TH6 = Right Auger
2. TH5 = Left Auger
3. TH4 = Right Refrigerant Valve
4. TH3 = Fan
5. TH2 = Compressor Relay
6. TH1 = Left Refrigerant Valve

Ultra LAF Triac Map (Bunn P/N 38983-0000)



1. Right Fill Valve (TH1)
2. Left Fill Valve (TH2)

