## **AXIOM®** Preventive Maintenance



In order to maintain proper operation and long service life BUNN® recommends performing the preventive maintenance every 6 months. Individual customers will vary with some customers choosing not to receive preventive maintenance.

	2 Flat head screwdrivers (1 small, 1 medium) Adjustable wrench Needle nose pliers Deliming tool (BUNN P/N: 38227.0000)
Pri	or to servicing the brewer: Disconnect the electrical supply Shut off water supply
PΝ	1 Steps
Ste	Remove probes from tank lid. Remove top and front access panels Drain tank using drain hose located behind front panel. Caution Hot Water!! Remove thermistor probe (temp probe) from the top of the tank. Clean and inspect Remove liquid level probes (2) from tank lid clean and inspect Reassembly is the opposite of disassembly
Ste	Rebuild brew valve, clean outlet fittings at tank.  Remove wire leads from brew valve  Carefully remove silicon hose from brew valve  Remove mounting nuts  Remove 4 screws from valve  Replace plunger, spring and rubber seat using rebuild kit, (BUNN P/N: 11517.0008)  Carefully remove the silicon hoses from the outlet tank fittings  Clean fittings using deliming tool (long end) or suitable tool  Reassembly is the opposite of disassembly
Ste	Rebuild hot water faucet. Replace hot water seat cup by unscrewing the bonnet assembly Remove old seat cup Install new seat cup, (BUNN P/N: 02766.0000) Reassembly is opposite of disassembly
Ste	ep 4: Clean and inspect Sprayhead clean spray head fitting. Clean and inspect Sprayhead Clean Sprayhead fitting using deliming tool
Step 5: Inspect brew funnel for missing or loose parts. Step 6: Inspect water connection points for signs of leakage.	

Step 7: Inspect power cord.

## Step 8:

- □ Return AXIOM® to service.
- Turn on water supply and check for leaks
- □ Plug AXIOM® in at wall receptacle
- Allow tank to fill and heat to operating temperature

## Step 9: Calibrate Sprayhead.

- Enter Level 2 programming.
- Scroll to the Calibrate Flow screen. This test is used to capture water from the sprayhead during a pre-deter mined 60 second dispense valve cycle.

CALIBRATE FLOW ?
NO YES

□ Ensure the sprayhead and funnel are in place and put a container, measuring pitcher or server, underneath the funnel, select Yes.

CONTAINER RDY?
QUIT YES

□ To activate the flow rate check, press the Brew button.

The valve will open for 60 seconds. Once all of the water has dripped out, use the (-) or (+) buttons to input the volume collected and select Done.

BREW OZ: 64.0 (-) DONE (+)