


SH SERVER SIGHT GAUGE GUIDE For 192 oz. Brew

INSTRUCTIONS

- 1. Select 1.5 Gallon Batch (no coffee in funnel) and press brew.
- 2. After drip out is complete, either use a tape measure to determine the distance from the bottom side of the sight gauge support to the water level in the sight gauge, or hold the left side of this guide next to the sight gauge to determine if water level is in the acceptable range. Distance should be between 27/16" 31/16".
- 3. If water level is within the acceptable range, brewer is ready for use. If not, the brewer should be calibrated.



BUNN-O-MATIC CORPORATION

POST OFFICE BOX 3227 SPRINGFIELD, ILLINOIS 62708-3227

PHONE: (217) 529-6601 FAX: (217) 529-6644

