
BUNN®

PAF DISPENSER LOCK KIT #34591.0000

INTRODUCTION:

This kit contains the necessary parts to install the dispenser lock mechanism on the ULTRA-2 with Powder Auto-Fill.

KIT CONTENTS:

34575.0000	Plate (2)
01533.0006	Spacer (2)
01330.0000	Screw #10-32 x 38" (2)
34573.0000	Latch Bracket (2)
01663.0000	Snap Bushing (2)
34561.0000	Decal (2)
32916.0002	Probe Retaining Kit (2)

WARNING: Disconnect the power source before the removal of any panel or replacement of any component.

Refer to illustration on back.

- 1) Disconnect the dispenser power cord from the platform assembly.
- 2) Disconnect the water lines from the dispenser.
- 3) Remove the dispenser from top of the platform.
- 4) Disconnect the light cord from top of the cooling drum support.
- 5) Replace the level probes on the hoppers with the dimpled probes included in the kit. Use existing screws.
- 6) Remove the two #8-32 screws attaching the platform support bracket to the platform housing.
- 7) Position the new lock bracket over the platform. Slip the light cord through the snap bushing on the bracket and plug back into receptacle on cooling drum support.
- 8) Align the holes in the bracket with the holes in the platform and support bracket. Reinstall the two #8-32 screws previously removed and tighten securely. Repeat for other side.
- 9) Remove the nylon latch from the rail located at the rear of the platform.
- 10) Install the dispenser back on the platform
- 11) Slide the PAF dispenser back and secure with the new Latch Bracket.
- 12) Remove the housing screw that aligns with the old nylon latch.
- 13) Install the new spacer and screw into the housing hole and tighten securely.
- 14) Install the guide plate onto the rail aligning the newly installed spacer with the .50" hole in the guide bracket. Reinstall the two screws previously removed and tighten securely.
- 15) Reconnect water lines to the dispenser.
- 16) Reconnect the dispenser power cord to the platform.
- 17) Reconnect the power supply to the ULTRA-2.
- 18) Apply Decal centered under plug inside front of the dispenser, as shown.

BUNN-O-MATIC CORPORATION

POST OFFICE BOX 3227
SPRINGFIELD, ILLINOIS 62708-3227
PHONE: (217) 529-6601 FAX: (217) 529-6644

