

JDF S Repair Checklist



The following steps should be followed after performing any repair on the JDF Silver Series dispensers. Upon completing a step, mark it off as being completed. This allows you to keep track of which steps you have completed. While completing the checklist if you notice something is not correct, please correct the item before leaving the location.

- Inspect air filter in the rear for cleanliness.
- Ensure cabinet is cool at or below refrigerated temperature.
- Inspect door gasket/seal for wear and cleanliness.
- Ensure both door lamps are lighted.
- Ensure dispenser is properly vented. Nothing sitting on top of the dispense covering the vent holes. Minimum 8 inches air clearance above the dispenser.
- Ensure machine placement has adequate distance in the rear from wall. Minimum is 4 inches for air clearance.
- Ensure warm air from other equipment is not blowing directly onto dispenser.
- Ensure all dispense stations are functioning.
- Inspect inside cabinet and around dispense platform area for any signs of leakage.
- Ensure all dispense nozzles are present.