

The following steps should be followed after performing any repair on the ITCB models. Upon completing a step, mark it off as being completed. This allows you to keep track of which steps you have completed. While completing the checklist if you notice something is not correct, please correct the item before leaving the location.

- ☐ Inspect the power cord for any wear or damage.
- ☐ Inspect all water lines and fittings for leaks, corrosion, or mineral build-up that may indicate a leak.
- ☐ Ensure the sprayhead is in place.
- ☐ Replace any leaking faucet seat cups.
- ☐ Clean any residue or scale build-up from sprayhead.
- ☐ Calibrate the flow rates.