

The following steps should be followed after performing any repair on the AutoPOD™ models. Upon completing a step, mark it off as being completed. This allows you to keep track of which steps you have completed. While completing the checklist if you notice something is not correct, please correct the item before leaving the location.

- ☐ Inspect for missing removable parts and replace. Drip tray and grate, booster tray and grate, pod bin and pod screen assembly.
- ☐ Check tank dispense temperature's against temperature set point in the program menu.
- ☐ Check large and small dispense volume against volume setting in programming.
- ☐ Clean stream guide tube.
- ☐ Inspect sprayhead gasket for wear or water leakage during brew.
- ☐ Remove and clean the sprayhead.
- ☐ Inspect the power cord for any wear or damage.
- ☐ Check operation of all switches.
- ☐ Check for any error message being displayed, diagnose and repair.
- ☐ Perform calibration of brew and hot water (H₂O) tank. Entering programming menu is required to perform this calibration process and a graduated measuring cup of at least 10 ounces is required.