AXIOM™ Installation Checklist



Placement Requirements

- □ Machine must be level front to rear and side to side (use of level is recommended)
- □ Countertop able to support machines weight (refer to manual)
- □ Counter area able to accommodate machine's footprint (refer to manual).

Water Treatment

- □ Sediment, chlorine, taste and odor filtration is highly recommended
- □ Water lines flushed prior to hook-up.

Water Supply

- Dedicated supply line from minimum ½" main line
- Cold water source mandatory
- □ ¼ "flare water connection ¼" male fitting supplied with equipment
- Dedicated shutoff valve should be installed on supply line in a convenient location for future use
- □ Dynamic water pressure between 20 and 90 psi. Over 90 psi. Pressure regulator adjusted to 50 psi is to be installed
- No leaks at any connection point

Electrical

- Dedicated circuit rated for model being installed (refer to installation manual)
- □ Insure both the wall receptacle and circuit breaker comply with all Federal, State and local codes
- □ Ensure power cord is plugged in completely and locked (if applicable)
- □ When field wiring on Dual Voltage equipment ensure proper gauge power cord is installed

Rev. 06/09/09