AutoPOD™ Accessing the Inside of the Brewer



Accessing the Inside of the Brewer

The majority of service work done to the AutoPOD™ brewer will require the service technician to access the inside of the unit. The brewer has three removable panels to facilitate access- the main housing, top cover and rear panel. Depending on the repair the technician may have to remove one or all of these panels.

In order to work safely the power should be disconnected prior to removal of any body panel. Once the panels are removed the power can be reconnected in order to troubleshoot the machine.

Remove Panels

- Step 1: Disconnect unit from power.
- **Step 2**: Use a standard screwdriver and remove the two screws from the top cover of the unit. Lift the top cover up and away from the unit.
- **Step 3**: Move the rear of the unit and remove the six standard screws securing the back panel. Pull the panel back and away from the unit.
- Step 4: Return to the front of the unit and pull the pod bin out and set aside.
- Step 5: Locate the three standard screws found on the bottom edge of the unit below the user interface.
- **Step 6**: Turn the unit so that the right side is facing you. Tilt the unit upward to access the underside and remove the right side standard screw.
- **Step 7**: Turn the unit so that the left side is facing you. Tilt the unit upward to access the underside and remove the left side standard screw.
- Step 8: Turn the unit so that the front is facing you and then slide the main housing out away from the unit frame.

