

ITCB Calibrating the Dilution Flow Rate



This function allows the operator to test and enter the actual flow rate of the bypass/dilution.

- Step 1:** Place the measuring container with a minimum capacity of 130 ounces beneath the dilution nozzle on the brewer. Water can also be dispensed into the server and then into the measuring container.
- Step 2:** Press and hold the right hidden switch to enter level 2 programming. Continue to press the right hidden switch until the display reads "Calibrate Flow?".
- Step 3:** Press and release YES to advance to the "Sprayhead Cal?" function screen.
- Step 4:** Press and release NO to advance to the "Dilution Calibration" screen.
- Step 5:** Press YES. The display will read "Container Ready?" If the container is under the nozzle, press YES. The display should read "Calibrate Dilute .. Press Brew to Start".
- Step 6:** Press and release the BREW switch. The display will read "Calibrate Dilute.... 60 Sec to Finish". The 60 second timer on the display will count down to zero. When the counter reaches zero, the display will change to "Dilute OZ/M" along with the existing ounces per minute.
- Step 7:** Measure the amount of water in the container and using the (-) or (+), adjust the amount on the display to match the amount in the container. Then press DONE.
- Step 8:** The display should now read "New Dilute Flow" along with the correct flow rate of the bypass in ounces per minute. After about 5 seconds, the display will return to the "Calibrate Flow?" screen.

